

# TVisto


---

## Quick Installation Guide



## (1) Install the Hard Drive

Open the enclosure, install and connect your hard drive but be careful not to damage any pins or components! For IDE drives, the jumper setting should be set to Master. Fasten the hard drive to the frame with three screws as seen below. Replace the cover and fasten the screws.



## (2) Format the Hard Drive

Create a **single primary** partition and format the drive. For further details regarding NTFS/FAT32/HFS+ file formats, refer to the User Guide.

## (3) Create the Directories

Create four (4) empty directories, named exactly as follows:


- **Firmware**
- **Movies**
- **Music**
- **Pictures**

## (4) Copy the Files and Data

Copy your files from your computer to the 'TVisto'. Movie files to the folder "Movies", Audio files to the folder "Music" and Images to the folder "Pictures".

## (5) Connect it to the TV

Connect the 'TVisto' to your TV, connect the power supply to the wall socket and then use the remote control for further commands. **Press the "TV out" button to toggle between the different TV formats if you do not see the 'TVisto' on your TV screen after 30 seconds.** Done! Your unit is now ready for use.



## Safety Information

### Power on/off precautions

It is highly recommended to switch the unit off (using the remote control) when not in use for longer periods of time.

Note: TVisto will switch to stand-by mode automatically if idle for more than 30 minutes.

### Location and placing precautions

Set the TVisto unit up in a vertical position and DO NOT place any other objects on top of the unit. Do not place the unit on an amplifier or other equipment that can become hot. Avoid positioning your TVisto device in the following places:

- Locations with direct sunlight, next to radiators or other sources of heat.
- Locations with very high temperature (more than 35° C) or humidity (more than 90%) a for prolong period of time.
- Very dusty or sandy locations.
- Locations subject to vibration, shock, or with a sloping base.

### Electricity and power plug

Careful attention must be paid to the following points in order to avoid operational faults with the equipment and to prevent electric shock, fire, and injury:

- When removing the power cable from the socket, always pull on the plug and never on the cable.
- Do not connect or remove the power cable with wet hands.
- Never try to repair the power cable yourself or to modify it in any way.
- If the unit is dropped or becomes damaged in any other way, unplug the power cable.
- If the unit should emit smoke, unusual smell or noise, switch it off and unplug the power cable. Please contact your dealer.
- If the unit is not used for an extended period of time, then the power plug should be removed from the socket.

### Cables

Use only the cables supplied or recommended by your vendor in order to avoid the risk of malfunction, electric shock or possible interference with the device.